



Einhell

EXPERT

POWER X-CHANGE

Tondeuse à gazon sans fil
GE-CM 36 Li Kit (2x3,0Ah)

Item No.: 3413060

Ident No.: 21071

Bar Code: 4006825582604

The GE-CM 36 Li cordless lawn mower is a high-quality, reliable and extremely powerful tool which cares for medium-size lawns without being connected to a socket. With the new Power X-Change battery system from Einhell the lawn mower has two powerful 18 V battery packs with 3.0 Ah for long work sessions without any bothersome power cables. For simple, individual adjustment of the cutting height there is a central 6-level cutting height adjustment facility.

Features & Benefits



Technical Data

- Batterie	18 V (2x) 3000 mAh Li-Ion
- Durée de fonctionnement maximum	30 min
- Temps de chargement	1h
- Vitesse de ralenti	3400 min ⁻¹
- Largeur de coupe	36 cm
- Ajustement de la hauteur de coupe	6 25-75 mm central
- Capacité du sac de récupération	40 L
- Diamètre de la roue avant	145 mm
- Diamètre de roue arrière	220 mm



Logistic Data

- Poids brut	19.5
- Poids du produit (kg)	16.9
- Dimension du packaging unitaire	765 x 490 x 370 mm
- Unité par carton de suremballage	1 Pieces
- Poids brut du carton d'exportation	19.5 kg
- Dimension du carton de sur-emballage	765 x 490 x 370 mm
- Unité par container (20"/40"/40" HC)	198 432 503



Available as special accessories



Spare Blade GE-CM 36 Li
Lawn Mower Accessory
Item No.: 3405485
Bar Code: 4006825584509
Einhell Grey



18V 4-6Ah Multi-Ah PXC Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



18V 2,0Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah Power X-Change
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



18V 5,2Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB 1
Battery
Item No.: 4511489
Bar Code: 4006825638578
Einhell Accessory



Power X-Boostcharger 6A
Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory



18V 3,0 Ah Power-X-Change 2
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 3,0Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512083
Bar Code: 4006825638509
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



18V 4,0Ah Power X-Change 1
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x 18V 2,5Ah PXC-Twinpack CB
Battery
Item No.: 4511524
Bar Code: 4006825656206
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 3,0Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory

Battery-Running-Times



One Battery for All

Tonte de gazon¹
(m²)

1.5 Ah	175
2.0 Ah	240
2.5 Ah	280
3.0 Ah	350
4.0 Ah	480
5.2 Ah	600
6.0 Ah	700
8.0 Ah	960

Test setup:

1) Gazon