Einhell

EXPERT PLUS

POWER X-CHANGE

Taille-Haie sans fil

GC-CH 1846 Li-Solo

Item No.: 3410642

Ident No.: 21041

Bar Code: 4006825588293

Le taille-haies sans fil GC-CH 1846 Li Solo est un outil puissant qui, grâce à son poids léger et à sa taille idéale pour une bonne maniabilité, permet un entretien particulièrement confortable et sans fil des haies, arbustes et buissons sur de grands terrains et dans les potagers. L'engrenage métallique assure une longue durée de vie et les lames en acier découpées au laser et affûtées au diamant garantissent des résultats de coupe impeccables.

Features & Benefits

- Petit et maniable
- Poids léger pour un travail confortable
- Engrenage métallique pour une longue durée de vie
- Interrupteur de sécurité à 2 mains
- Guide porte-lame en alu
- Butée de protection avec accroche murale
- Lames en acier découpées au laser et affûtées au diamant
- Fourreau solide pour le rangement et le transport
- Livré sans batterie et sans chargeur (disponibles séparément)

Technical Data

- Longueur de la lame	520 mm
- Longeur de coupe	460 mm
- Espacement entre les dents	15 mm
- Coupes par minute	2200 min^-1

Logistic Data

- Poids du produit	2 kg
- Poids brut a l'unité	2.84 kg
- Dimension du packaging unitaire	892 x 180 x 185 mm
- Unité par carton de suremballage	4 Pieces
- Poids brut du carton d'exportation	11.36 kg
- Dimension du carton de sur-emballage	915 x 375 x 265 mm
- Unité par container (20"/40"/40" HC)	1152 | 2400 | 3000



Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory

Available as special accessories

18V 2,0Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory

18V 4,0Ah Power X-Change 1 Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory

18V 4,0Ah PXC Starter Kit 1 PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

18V 5,2Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory

Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory

18V 2,0Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory

Power X-Boostcharger 6A Charger
Item No.: 4512064
Bar Code: 4006825629019
Einhell Accessory

18V 3,0 Ah Power-X-Change 2 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory

Battery-Running-Times

One Battery for All	Autonomie[1] (min.)
1.5 Ah	60
2.0 Ah	80
2.5 Ah	100
3.0 Ah	120
4.0 Ah	160
5.2 Ah	210
6.0 Ah	240

Test setup:

1) -

Illustrations can contain accessories, which are not included in standard extent of delivery
Illustration similar (in design), production-wise modifications reserved
GS mark belongs to the product itself only, excluded accessory